One (1) FindFiber Remote ID

Tekniset tiedot

Tips for Using FindFiber

- FindFiber has an SC connection at the top, under the protective cap. It uses a Class 1 Laser to send a signal to the SimpliFiber Pro Meter, which will display the remote ID number set by the user.

- Press the Mode button on SimpliFiber Pro Meter to place it in FindFiber mode, and it will display the number indicated on the FindFiber source as long as the fiber link connecting the meter and source is good.
- If your fiber link uses a different connector type than SC, you can use hybrid patch cords to (SC-LC for example) to connect the FindFibe Remote ID to it.
- FindFiber does not have VFL capability